

ENERGY EFFICIENCY MANUAL

by Donald R. Wulfinghoff

List of Measures and Reference Notes

This is a complete listing of the Measures and the Reference Notes in the *Energy Efficiency Manual*, along with the page numbers where they are found. This list is intended as an aid when using the *Manual*. It should NOT be used alone for selecting energy conservation activities. Developing a rational energy conservation program requires the Ratings, Selection Scorecard, Economics, and other selection guides that are provided for each Measure. Refer to the *Manual* for detailed guidance in accomplishing each of these Measures and keeping them successful. For extensive information about the *Energy Efficiency Manual*, visit:

www.EnergyBooks.com

Section 1: BOILER PLANT

Subsection 1.1: EQUIPMENT SCHEDULING AND OPERATING PRACTICES

1.1.1 Minimize the duration of boiler plant operation.	20
1.1.1.1 For applications with regular schedules, install clock controls to start and stop boilers.	22
1.1.1.2 In applications that require a warm-up period, control boiler operation using an optimum-start controller.	23
1.1.1.3 If the boiler plant is used only for comfort heating, limit the operation of the boiler plant based on the outside air temperature.	25
1.1.1.4 In applications where automatic starting and stopping of boilers is not desirable, use automatic controls to signal the starting and shutdown sequence to operators.	27
1.1.2 With multi-fuel boilers, select the most economical fuel on a moment-to-moment basis.	28
1.1.2.1 Install automatic fuel changeover.	30
1.1.3 Operate boiler auxiliary equipment consistent with boiler operation and load.	31
1.1.3.1 Interlock auxiliary equipment with the boilers it serves.	33
1.1.3.2 Install power switching that prevents unnecessary operation of spare pumps.	34
1.1.4 Distribute the heating load among boilers in the manner that minimizes total plant operating cost.	34
1.1.4.1 Install an automatic boiler scheduling controller.	38
1.1.5 In steam systems, keep steam pressure at the minimum that satisfies equipment and distribution requirements.	40

Subsection 1.2: BOILER PLANT EFFICIENCY MEASUREMENT

1.2.1 Test boiler efficiency on a continuing basis.	44
1.2.2 Install efficiency instrumentation appropriate for the boiler plant.	54
1.2.3 Calibrate boiler plant instruments at appropriate intervals.	57
1.2.4 Keep operators proficient in using instrumentation to maximize boiler plant efficiency.	58

Subsection 1.3: AIR-FUEL RATIO

1.3.1 Optimize the air-fuel ratio.	60
1.3.2 Install automatic air-fuel mixture controls.	65
1.3.3 Adjust and repair air-fuel ratio controls.	69

Subsection 1.4: BURNER AND FAN SYSTEMS

1.4.1 Clean, adjust, and repair burner assemblies at appropriate intervals.	72
1.4.2 Eliminate air leaks in air casings, blower housings, and connecting ducts.	74
1.4.3 In boilers that are fired at inefficiently high output, reduce the maximum firing rate.	75
1.4.4 Install burner systems that provide the best efficiency and other features.	78
1.4.5 Replace the motors in burners and fans with models having the highest economical efficiency.	89
1.4.6 Replace continuous pilot flames with electrical ignition.	89
1.4.7 Install variable-output fan drives on large forced-draft and induced-draft fans.	90

Subsection 1.5: DRAFT CONTROL

1.5.1 Adjust draft for maximum efficiency.	94
1.5.2 Correct defects in flue systems and boiler room ventilation that cause draft problems.	99
1.5.3 Minimize standby losses.	102
1.5.3.1 Control all fans in the combustion air path to stop, and all dampers to close, when the burner is not firing.	103
1.5.3.2 Install an automatic flue damper.	104
1.5.3.3 Install a burner assembly or boiler that minimizes standby losses.	106
1.5.3.4 With cycling burners, adjust the controls to minimize the frequency of firing cycles.	106

Subsection 1.6: FIRESIDES AND WATERSIDES

1.6.1 Clean firesides at appropriate intervals.	110
1.6.2 Install soot blowers in boilers that burn sooting fuels.	112
1.6.3 Optimize soot blower operation.	115
1.6.4 Clean watersides at appropriate intervals.	116
1.6.5 Avoid leaving waterside deposits when deactivating boilers.	118

Subsection 1.7: COMBUSTION GAS HEAT TRANSFER AND HEAT RECOVERY

1.7.1 Install a flue gas heat exchanger to recover additional heat.	120
1.7.1.1 Install a conventional (non-condensing) economizer.	121
1.7.1.2 Install a heat recovery air preheater.	126
1.7.1.3 Install a condensing economizer.	129
1.7.1.4 Install a water spray heat recovery unit.	131
1.7.2 In firetube boilers, install turbulators.	133

Subsection 1.8: CONDENSATE, FEEDWATER, AND WATER TREATMENT

1.8.1 Test and treat boiler water on a continuing basis.	142
1.8.1.1 Hire a qualified consultant and contractor to perform water treatment.	150
1.8.1.2 Install automatic water treatment equipment.	152
1.8.2 Control top and bottom blowdown to maintain required water quality and minimize waste of boiler water.	153
1.8.2.1 Install automatic blowdown control.	157
1.8.3 Install blowdown heat recovery.	158
1.8.4 Maximize condensate return.	163
1.8.4.1 Recover the heat from condensate that must be discarded.	166
1.8.4.2 Recover the energy of high-temperature condensate that would be lost by flashing.	167
1.8.5 Keep vacuum condensate systems operating properly.	169
1.8.6 Replace pump motors with models having the highest economical efficiency.	171

Subsection 1.9: FUEL OIL SYSTEMS

1.9.1 Adjust fuel oil temperature to provide the optimum viscosity for burner efficiency.	174
1.9.1.1 Install automatic fuel oil viscosity control equipment.	176
1.9.2 Use the most economical heat source for fuel oil heating.	177
1.9.3 Use fuel oil additives to improve combustion efficiency and/or improve other fuel oil properties.	178
1.9.4 Replace pump motors with models having the highest economical efficiency.	180

Subsection 1.10: STEAM AND WATER LEAKAGE

1.10.1 Monitor boiler system water loss.	182
1.10.2 Locate and repair steam and water leaks at appropriate intervals.	183
1.10.3 Use the most efficient type of steam trap for each application.	187
1.10.4 Test and repair steam traps on a continuing basis.	198
1.10.4.1 Install accessory devices to assist in steam trap diagnosis.	203
1.10.4.2 Hire specialists to perform periodic steam trap inspections.	207
1.10.5 Recover heat and water from steam vents.	208

Subsection 1.11: CONDUCTION AND RADIATION LOSSES

1.11.1 Locate and repair defective insulation on all heating plant equipment and piping.	212
1.11.2 Minimize cooling or ventilation of pipe tunnels and other unoccupied spaces surrounding hot distribution equipment.	216
1.11.3 Route combustion air to the boiler by a path that recovers heat from the boiler room.	218

Subsection 1.12: SYSTEM DESIGN FOR EFFICIENT LOW-LOAD HEATING

1.12.1 In facilities that operate for extended periods with low heating loads, install a small, efficient lead boiler.	226
1.12.2 Install localized heating units to allow shutting down the central plant during periods of low load.	230
1.12.3 If it is desirable to reduce the boiler operating pressure, eliminate high-pressure steam users or provide separate high- pressure steam boilers.	232
1.12.4 If a facility has several boiler plants, provide cross connections that allow shutting down the least efficient boilers.	233

Section 2: CHILLER PLANT

Subsection 2.1: EQUIPMENT SCHEDULING AND OPERATING PRACTICES

2.1.1	Distribute the cooling load among chillers in the manner that minimizes total plant operating cost.	240
2.1.1.1	Install an automatic chiller scheduling controller.	243
2.1.2	Use automatic controls to shut down the entire chiller plant when there is no cooling load.	245
2.1.2.1	Control chiller plant operation by sensing the end-user cooling load.	246
2.1.2.2	Limit the operation of the chiller plant based on the temperature or enthalpy of the outside air.	247
2.1.2.3	In applications with regular schedules, use time controls.	249
2.1.2.4	In applications where pre-cooling is required, use optimum-start controllers.	249
2.1.2.5	In applications where automatic starting of chillers is undesirable, use automatic controls to alert personnel to start them manually.	250
2.1.3	Turn off and isolate heat rejection equipment when the corresponding chiller turns off.	250
2.1.4	In plants with multiple water chillers, minimize the operation of chilled water pumps and isolate idle evaporators.	253
2.1.5	Install power switching that prevents unnecessary operation of spare pumps.	260
2.1.6	Turn off compressor sump/crankcase heaters during extended shutdown intervals.	261

Subsection 2.2: OPTIMUM OPERATING TEMPERATURES

2.2.1	Keep the chilled water supply temperature as high as possible.	264
2.2.1.1	Reset chilled water temperature manually.	265
2.2.1.2	Install an automatic chilled water temperature controller.	266
2.2.2	Optimize the condensing temperature.	267
2.2.2.1	Adjust the condenser temperature manually.	270
2.2.2.2	Install automatic condenser temperature reset controls.	272

Subsection 2.3: CONDENSER AND EVAPORATOR HEAT TRANSFER EFFICIENCY

2.3.1	In systems with open-loop cooling towers, clean condenser tube watersides regularly.	276
2.3.1.1	Install automatic condenser tube cleaners.	277
2.3.2	With water chillers, clean evaporator tube watersides at appropriate intervals.	279
2.3.3	With wet condenser cooling systems, test and treat cooling water on a continuing basis.	280
2.3.3.1	Hire a qualified consultant and contractor to perform water treatment.	282
2.3.3.2	Install and maintain automatic chemical feeders.	282
2.3.4	In wet cooling systems, adjust the bleed rate to maintain proper water conditions with minimum water consumption.	283
2.3.4.1	Install and maintain an automatic bleed control.	285
2.3.5	In chilled water systems, install turbulators in the evaporator tubes.	286

Subsection 2.4: HEAT REJECTION EQUIPMENT

2.4.1	Modulate fan output in heat rejection units to follow the cooling load.	291
2.4.1.1	Install variable-frequency fan drives.	295
2.4.1.2	Install variable-pitch propeller fans.	297
2.4.1.3	Install dual or multi-speed motors.	299
2.4.2	In multiple-cell cooling units, sequence the fans efficiently.	301
2.4.3	Clean heat rejection units at appropriate intervals.	302
2.4.3.1	Install and screen heat rejection units to minimize debris accumulation.	305
2.4.4	In gravity-flow cooling towers, ensure proper water distribution.	307
2.4.5	Keep heat rejection unit housings and fittings intact.	308
2.4.6	Avoid recirculation of air through the same or adjacent heat rejection units.	310
2.4.7	Install fan and pump motors having the highest economical efficiency.	315

Subsection 2.5: PUMP ENERGY CONSUMPTION

2.5.1	Adjust the discharge of pumps to match system flow and/or pressure requirements.	318
2.5.1.1	Trim pump impellers.	318
2.5.1.2	Throttle pump discharge valves.	319
2.5.2	Install variable-flow chilled water distribution.	319
2.5.3	Install pump motors having the highest economical efficiency.	330

Subsection 2.6: COMPRESSORS

2.6.1	If the compressor motor fails, replace it with a more efficient motor.	332
2.6.2	Replace inefficient compressors with efficient units.	333
2.6.3	In centrifugal chillers, install variable-speed compressor drives.	335

Subsection 2.7: REFRIGERANT CONDITION

2.7.1	Repair chiller system leaks.	338
2.7.2	Maintain the proper refrigerant charge.	342
2.7.3	Operate purge units appropriately.	347
2.7.3.1	Install high-efficiency purge units.	350
2.7.4	Install accessories that prevent air leakage into idle chillers.	352
2.7.5	Drain the water from the evaporators and condensers of idle chillers.	354

Subsection 2.8: SYSTEM DESIGN FOR EFFICIENT LOW-LOAD COOLING

2.8.1 Install chillers and auxiliary equipment of appropriate size to avoid extended operation at low load.	357
2.8.2 Install local cooling units to allow shutting down the central chiller plant during periods of low load.	361
2.8.3 If a facility has several chiller plants, provide cross connections that allow shutting down the least efficient chillers.	364

Subsection 2.9: EXPLOITING LOW AMBIENT TEMPERATURES FOR WATER CHILLING

2.9.1 Install chiller "free cooling".	371
2.9.2 Cool chilled water with a heat exchanger in the cooling tower circuit.	373
2.9.3 Install a strainer system to use cooling tower water directly in the chilled water system.	375
2.9.4 Install a "waterside economizer" using separate cooling coils.	379
2.9.5 Install a closed-loop atmospheric cooling unit in the chilled water circuit.	382

Subsection 2.10: HEAT RECOVERY FROM CHILLERS

2.10.1 Use condenser water directly for heating applications.	389
2.10.2 Use an auxiliary condenser or double-bundle condenser for heat recovery.	391
2.10.3 To recover large amounts of heat at elevated condensing temperature, install a heat recovery chiller.	394
2.10.4 To recover small quantities of heat at maximum temperature, install a desuperheater.	397
2.10.5 Improve the quantity or economics of heat recovery by adding or increasing heat storage.	400

Subsection 2.11: COOLING THERMAL STORAGE

2.11.1 Install cooling thermal storage.	406
--	-----

Section 3: SERVICE WATER SYSTEMS

Subsection 3.1: REDUCING SERVICE WATER CONSUMPTION

3.1.1 Repair water fixtures regularly.	440
3.1.2 Install efficient wash basin fixtures.	443
3.1.3 Install efficient shower heads.	445
3.1.4 Install shower valves that allow easy control of temperature and flow rate.	448
3.1.5 Provide instructions for efficient use of water in showers and lavatories.	450
3.1.6 Install efficient toilets.	451
3.1.7 Install efficient urinals or improve existing urinals.	453

Subsection 3.2: WATER HEATING SYSTEMS

3.2.1 Minimize the hot water temperature.	458
3.2.1.1 Use low-temperature detergents.	461
3.2.2 Install a separate high-temperature water heater for high- temperature applications.	462
3.2.3 Install water heaters that have the lowest energy cost and highest efficiency.	463
3.2.4 Install supplemental insulation on water heaters.	468
3.2.5 Install automatic flue dampers on fuel-fired water heaters.	469
3.2.6 Clean and adjust the combustion systems of fuel-fired water heaters periodically.	470
3.2.7 Clean out scale from water heaters periodically.	471
3.2.8 Exploit interruptible or storage rates for electric water heating.	473
3.2.9 Control electric water heating to reduce demand charges.	477

Subsection 3.3: SERVICE WATER PUMPING

3.3.1 In facilities that have their own service water pumps, configure the system to minimize pump energy consumption.	480
3.3.1.1 Use multiple pressurization pumps.	484
3.3.1.2 Install gravity tanks or pressurized storage tanks.	488
3.3.2 Design hot water recirculation to minimize pump energy.	492
3.3.3 Trim pump impellers to eliminate excess system pressure.	495
3.3.4 Install power switching that prevents unnecessary operation of spare pumps.	495
3.3.5 Install pump motors having the highest economical efficiency.	496

Section 4: AIR HANDLING SYSTEMS

Subsection 4.1: MINIMIZING DURATION OF OPERATION

4.1.1 Turn off air handling systems when they are not needed.	506
4.1.1.1 Where spaces operate on regular schedules, use timeclocks to start and stop air handling equipment.	507
4.1.1.2 Install optimum-start controllers to adapt starting times to weather conditions.	509
4.1.1.3 In spaces with irregular usage, install rundown timer switches to provide user control of air handling system operation.	511
4.1.1.4 In spaces with irregular usage, install personnel sensors to control air handling equipment.	513
4.1.1.5 Assign responsibility for operating air handling systems to the personnel who administer the spaces.	515
4.1.1.6 In applications where automatic starting and stopping of air handling units is undesirable and operators are on duty, use automatic controls to alert operators to turn systems on and off.	516

Subsection 4.2: OUTSIDE AIR INTAKE AND BUILDING PRESSURIZATION

4.2.1 Adjust outside air intake to the minimum needed to satisfy comfort, health, and code requirements, and to maintain proper building pressurization.	519
4.2.1.1 During periods of reduced occupancy, control outside air dampers and exhaust fans to reduce the quantity of ventilation air appropriately.	527
4.2.1.2 Control outside air intake by sensing air contaminants.	530
4.2.2 Provide accurate control of outside air intake and building pressurization by adding a return fan or relief fans and improving the damper configuration.	532
4.2.3 Where once-through air handling systems are installed unnecessarily, modify them to provide recirculation.	538
4.2.4 Use air cleaning to reduce the need for outside air ventilation.	539
4.2.5 Provide outside air economizer cycle operation of air handling units.	547
4.2.6 Install enthalpy control of economizer cycles.	551
4.2.7 Install a purge cycle for overnight cooling.	553
4.2.8 Install an exhaust air heat recovery system.	555
4.2.9 Improve the envelope penetrations of air handling systems to minimize air quality problems, wind problems, and energy requirements.	563
4.2.10 Minimize the use of extra heat for freeze protection.	568
4.2.11 Eliminate air handling system stratification that increases energy consumption or reduces comfort.	573

Subsection 4.3: SINGLE-ZONE SYSTEMS

4.3.1	Install placards at user controls to encourage efficient operation.	581
4.3.2	If conditioning cannot be turned off during unoccupied hours, install temperature setback.	583
4.3.3	Match fan output to the conditioning load.	585
4.3.3.1	Trim fan output.	588
4.3.3.2	Cycle the running of the fans and other air handling system equipment with the space thermostat.	588
4.3.3.3	Install multi-speed fan motors.	591
4.3.3.4	Convert the system to VAV operation.	593
4.3.4	Install thermostatic controls that allow space temperature to drift within comfortable limits.	596
4.3.4.1	Install thermostats that require manual switching between heating and cooling.	597
4.3.4.2	Install deadband thermostats.	600
4.3.4.3	Adjust or modify the coil controls to increase deadband.	603

Subsection 4.4: SINGLE-DUCT REHEAT SYSTEMS

4.4.1	Set the cooling coil discharge at the highest temperature that maintains satisfactory cooling.	607
4.4.1.1	Install automatic chilled air temperature reset control.	610
4.4.2	Turn off the air handling unit cooling coils when cooling is not needed.	612
4.4.3	Turn off reheat coils when practical.	613
4.4.4	In terminal units that blend supply air with reheated air, block the reheat passages during the cooling season.	614
4.4.5	Trim the fan output.	615
4.4.6	Install multi-speed fan motors.	616
4.4.7	Convert the system to variable-air-volume (VAV) operation.	618
4.4.8	Replace all reheat coils in a system with heating/cooling coils and minimize operation of the air handling unit cooling coil.	631
4.4.9	Install self-contained heating/cooling units, and use the air handling system only for ventilation.	634

Subsection 4.5: DUAL-DUCT REHEAT SYSTEMS

4.5.1	Keep the temperature of the cold duct as high as possible and the temperature of the hot duct as low as possible.	640
4.5.1.1	Install temperature reset controllers for both the cold duct and the hot duct.	642
4.5.2	Turn off the heating coil and/or the cooling coil whenever practical.	643
4.5.3	Trim the output of the air handling system fans.	644
4.5.4	Install multi-speed fan motors.	644
4.5.5	Convert the system to variable-air-volume (VAV) operation.	644

Subsection 4.6: MULTIZONE SYSTEMS

4.6.1 Keep the temperature of the cold deck as high as possible and the temperature of the hot deck as low as possible.	654
4.6.1.1 Install temperature reset controllers for both the cold deck and the hot deck.	654
4.6.2 Turn off the cooling coil or the heating coil whenever practical.	654
4.6.3 Trim fan output.	655
4.6.4 Install multi-speed fan motors.	655
4.6.5 Convert the system to variable-air-volume (VAV) operation.	656

Subsection 4.7: VARIABLE-AIR-VOLUME SINGLE-DUCT SYSTEMS

4.7.1 In spaces with shutoff VAV terminals, install thermostat placards.	662
4.7.2 In spaces with shutoff VAV terminals, install deadband thermostats.	664
4.7.3 If the air handling systems be turned off during unoccupied hours, install temperature setback.	667
4.7.4 Turn off the air handling unit cooling coil when cooling is not needed.	669
4.7.5 Minimize the minimum-flow settings of terminal units.	670
4.7.6 Set the cooling coil discharge at the highest temperature that maintains satisfactory cooling.	672
4.7.6.1 Install automatic chilled air temperature reset control.	673
4.7.7 With minimum-flow terminals, install heating/cooling changeover.	674
4.7.8 Improve the efficiency of fan modulation.	677

Subsection 4.8: VARIABLE-AIR-VOLUME DUAL-DUCT SYSTEMS

4.8.1 In spaces with shutoff VAV terminals, install temperature setting placards on thermostats.	683
4.8.2 In spaces with shutoff VAV terminals, modify thermostatic controls to maximize deadband.	683
4.8.3 If air handling equipment cannot be turned off during unoccupied hours, install temperature setback.	684
4.8.4 Turn off the heating coil and/or the cooling coil whenever practical.	684
4.8.5 Adjust minimum-flow terminals to minimize overlap of hot and cold air flow.	685
4.8.6 Keep the cold duct temperature as high as possible and the hot duct temperature as low as possible.	687
4.8.6.1 Install duct temperature reset controllers for both the cold duct and the hot duct.	688
4.8.7 Improve the efficiency of fan modulation.	688
4.8.8 Install an outside air economizer cycle with separate hot and cold duct fans.	689

Subsection 4.9: INDUCTION SYSTEMS

4.9.1 Maximize the primary air temperature.	693
4.9.1.1 Install automatic temperature reset control for the primary air.	694
4.9.2 Turn off the air handling unit cooling coil when cooling is not needed.	695
4.9.3 Install temperature setback.	696
4.9.4 Clean, adjust, and repair induction terminal units at appropriate intervals.	698
4.9.5 Avoid discharging conditioned air on exterior surfaces.	699

**Section 5: ROOM CONDITIONING UNITS
AND SELF-CONTAINED HVAC EQUIPMENT**

Subsection 5.1: MINIMIZING EQUIPMENT OPERATION

5.1.1 Install placards at the controls of conditioning units to motivate efficient operation.	704
5.1.2 Assign responsibility for turning conditioning units on and off to security personnel or to those who administer the spaces.	708
5.1.3 Install automatic controls to turn off conditioning units when they are not needed.	709
5.1.3.1 Where spaces operate on regular schedules, use setback thermostats or timeclocks to control the operation of conditioning units.	711
5.1.3.2 In spaces with irregular usage, install timed-turnoff switches to provide user control of conditioning units.	714
5.1.3.3 In spaces with irregular usage, install personnel sensors to control conditioning equipment.	714
5.1.3.4 Connect the power to conditioning units through an appropriate light switch.	714
5.1.4 Install proximity switches to turn off conditioning units when doors and windows are left open.	716

Subsection 5.2: RADIATORS AND CONVECTORS

5.2.1 Clean and repair radiators and convectors at appropriate intervals.	720
5.2.2 Install thermostatic control valves on units with manual valves.	721
5.2.3 On units with manual control valves, provide easy and safe access to the valves.	724
5.2.4 Ensure that convection and radiation are not obstructed by enclosures or other objects.	725
5.2.5 Avoid trapping of heat output against exterior walls.	727
5.2.6 Thermally isolate radiators and convectors from poorly insulated walls.	729
5.2.7 With steam heating, install a vacuum condensate system to improve temperature control.	731
5.2.8 Convert steam heating to hydronic heating.	733
5.2.9 Replace electric resistance convectors with heating units having lower energy cost.	736
5.2.10 Provide separate thermostatic control for each area with distinct heating requirements.	738

Subsection 5.3: FAN-COIL UNITS

5.3.1 Clean, adjust, lubricate, and repair fan-coil units at appropriate intervals.	742
5.3.2 Select high-efficiency motors in new fan-coil units and when replacing failed motors.	744
5.3.3 Keep conditioned air from discharging on windows and exterior walls.	745
5.3.4 Install thermostatic controls that allow space temperature to drift within comfortable limits.	747
5.3.5 Convert 3-pipe systems to 2-pipe operation.	748
5.3.6 Convert 3-pipe systems to 4-pipe systems.	751
5.3.7 Replace electric resistance heating units with equipment having the lowest practical energy cost.	752

Subsection 5.4: SELF-CONTAINED AIR CONDITIONERS AND THROUGH-WALL HEAT PUMPS

5.4.1 Clean, adjust, lubricate, and repair through-wall air conditioners and heat pumps at appropriate intervals.	754
5.4.2 Install high-efficiency replacement fan motors.	756
5.4.3 Seal through-wall conditioning units to prevent outside air infiltration.	757
5.4.4 In units that provide outside air ventilation by exhausting conditioned air, abolish this feature.	758
5.4.5 Install air conditioning units and heat pumps having the highest practical efficiency.	759
5.4.6 If electric heating elements are installed with air conditioners, replace them with heating units having lower energy cost.	761

Subsection 5.5: REMOTELY COOLED AIR CONDITIONING UNITS AND HEAT PUMPS

5.5.1 Clean, adjust, lubricate, and repair air conditioners and heat pumps at appropriate intervals.	765
5.5.2 Replace fan, pump, and compressor motors with models having the highest economical efficiency.	766
5.5.3 Install compressors or new conditioning units having the highest economical efficiency.	767
5.5.4 Optimize the condenser temperature setting.	768
5.5.5 Turn off sump/crankcase heaters during extended shutdown intervals.	770
5.5.6 Drain cooling towers and evaporative condensers during the season when they are not required, and turn off water sump heaters.	770
5.5.7 Replace electric heating elements in cooling units with heating equipment that has lower energy cost.	771
5.5.8 With cooling towers and evaporative condensers, interlock the operation of the pumps and fans with the operation of the compressors.	772
5.5.9 Recover condenser heat for preheating service water or other low-temperature heating applications.	773
5.5.10 Improve cooling efficiency by using alternative heat sinks and heating efficiency by using alternative free heat sources.	775

Subsection 5.6: HEAT PUMP LOOP SYSTEMS (ADDITIONAL MEASURES)

5.6.1	Install controls to optimize the loop temperature under all operating conditions.	785
5.6.2	Install automatic valves and bypass lines to prevent the flow of loop water through heat sources and heat sinks when they are not needed.	789
5.6.3	Improve efficiency by substituting a heat source/sink with better temperature characteristics, or by adding a source of free heat.	791
5.6.4	Add thermal storage to the loop system.	794

Subsection 5.7: DIRECT-FIRED HEATING UNITS

5.7.1	Clean, adjust, lubricate, and repair direct-fired heating units at appropriate intervals.	798
5.7.2	Install high-efficiency heating units.	799
5.7.3	Install automatic flue dampers on existing heaters.	802
5.7.4	Set the anticipators of space thermostats to maximize the interval between firing cycles.	804

Section 6: BUILDING AIR LEAKAGE**Subsection 6.1: PERSONNEL DOORS**

6.1.1	Maintain the fit, closure, and sealing of exterior doors.	808
6.1.2	Install appropriate weatherstripping on exterior doors.	809
6.1.3	Install effective closers on exterior doors.	811
6.1.3.1	If manual opening of doors is acceptable, install spring-type door closers.	811
6.1.3.2	If manual opening of doors is not acceptable, install automatic doors or door openers.	812
6.1.4	Install high-efficiency doors.	814
6.1.5	If a pressure differential at the entrance is unavoidable, install a revolving door.	815
6.1.6	If a revolving door is installed, encourage people to use it instead of other doors.	816
6.1.7	Install storm doors.	818
6.1.8	Install vestibules for doors with frequent traffic.	820
6.1.9	Seal abandoned doors.	823

Subsection 6.2: GARAGE, LOADING, AND EQUIPMENT DOORS

6.2.1 Maintain the fit, closure, and sealing of industrial-type doors.	826
6.2.2 Install infiltration seals on existing doors.	827
6.2.3 Install powered door operators.	830
6.2.4 Install efficient exterior doors.	833
6.2.5 Install lightweight quick-acting doors to supplement exterior doors and to separate interior spaces.	839
6.2.5.1 Install strip curtains.	840
6.2.5.2 Install fabric swing doors.	842
6.2.5.3 Install impact doors.	843
6.2.5.4 Install powered quick-acting vehicle doors.	846
6.2.6 Install dock-to-truck seals.	854

Subsection 6.3: WINDOW AIR LEAKAGE

6.3.1 Maintain the fit, closure, and sealing of windows.	860
6.3.2 Install weatherstripping on openable windows.	861
6.3.3 Install supplemental ("storm") windows.	862
6.3.4 Install high-efficiency windows.	862

Subsection 6.4: OTHER ENVELOPE LEAKAGE

6.4.1 Seal gaps in the envelope structure.	864
6.4.2 Install gaskets at wall switches and receptacles that allow outside air leakage.	868
6.4.3 Install roof and attic hatches that close tightly and reliably.	869
6.4.4 Adjust and repair space air vents periodically.	870
6.4.5 Ventilate elevator shafts rationally.	872

Section 7: BUILDING INSULATION

Subsection 7.1: ROOFS AND ATTICS

7.1.1 Increase the quantity of attic insulation.	876
7.1.2 Add rigid insulation to the top surface of roofs.	879
7.1.3 Apply sprayed foam insulation to the top surface of roofs.	882
7.1.4 Install insulation on the underside of roofs.	884
7.1.5 Install a suspended insulated ceiling.	886

Subsection 7.2: WALLS AND SOFFITS

7.2.1 Insulate wall cavities.	890
7.2.2 Insulate the inside surfaces of walls.	896
7.2.3 Insulate the outside surfaces of walls.	901
7.2.4 Increase the thermal resistance of the panels in curtain walls.	903

Subsection 7.3: GLAZING INSULATION

7.3.1 Install high-efficiency glazing.	908
7.3.2 Install storm windows or supplemental glazing.	908
7.3.3 Reduce the area of glazing.	911
7.3.4 Install thermal shutters.	911
7.3.5 Use window films that reflect heat back into the building.	912

Section 8: CONTROL AND USE OF SUNLIGHT

Subsection 8.1: REDUCING COOLING LOAD: WINDOWS & SKYLIGHTS

8.1.1 Install external shading devices appropriate for each exposure of the glazing.	919
8.1.2 Install internal shading devices.	930
8.1.3 Install high-efficiency glazing.	934
8.1.4 Install solar control films on existing glazing.	944
8.1.5 Reduce the area of glazing.	949

Subsection 8.2: REDUCING COOLING LOAD: OPAQUE SURFACES & OVERALL

8.2.1 Improve the insulation of surfaces exposed to sunlight.	954
8.2.2 Apply paint, coating, or sheathing that minimizes absorption of sunlight.	954
8.2.3 Provide effective ventilation of attics.	957
8.2.4 Plant trees and other foliage to provide shading.	961

Subsection 8.3: DAYLIGHTING

8.3.1 Install skylights or light pipes.	966
8.3.2 Install diffusers for existing clear skylights.	979
8.3.3 Install translucent roof and wall sections for daylighting.	983
8.3.4 Install diffusers to make windows more effective for daylighting.	994
8.3.5 Install a system of light shelves and shading.	1000
8.3.6 Use light interior colors or mirrored surfaces.	1006

Subsection 8.4: PASSIVE SOLAR HEATING

8.4.1 Keep open the window shades of unoccupied spaces that need heating.	1008
8.4.2 Install combinations of sunlight absorbers and reflectors inside windows and skylights.	1009
8.4.3 Install solar enclosures over areas that can benefit from heating.	1012

Section 9: ARTIFICIAL LIGHTING

Subsection 9.1: LAMPS AND FIXTURES, INCANDESCENT

9.1.1 Eliminate excessive lighting by reducing the total lamp wattage in each activity area.	1023
9.1.2 Substitute higher-efficiency lamps in existing fixtures.	1025
9.1.2.1 Substitute screw-in fluorescent lamps for incandescent lamps.	1025
9.1.2.2 Substitute tungsten halogen lamps for conventional incandescent lamps.	1031
9.1.3 Substitute lamps that minimize light trapping and/or improve light distribution.	1033
9.1.4 Modify existing fixtures to reduce light trapping and/or improve light distribution.	1036
9.1.4.1 In fixtures having shades that absorb light, modify or eliminate the shades.	1036
9.1.4.2 Install reflective inserts in fixtures that have absorptive internal baffles or surfaces.	1038
9.1.4.3 For task lighting, install focussing lamps on flexible extensions.	1039
9.1.5 Replace incandescent fixtures with fluorescent or HID fixtures.	1040
9.1.6 Modify or replace incandescent exit signs with fluorescent or LED light sources.	1041
9.1.7 Install dimmers.	1042

Subsection 9.2: LAMPS AND FIXTURES, FLUORESCENT

9.2.1 Eliminate excessive lighting by removing lamps and disconnecting or removing their ballasts.	1046
9.2.1.1 To remove single tubes from 2-tube ballasts, substitute dummy lamps.	1050
9.2.1.2 To remove single tubes where 2-tube ballasts are installed, substitute single-tube ballasts.	1051
9.2.1.3 To remove single tubes from groups of fixtures, rewire the ballasts between fixtures.	1052
9.2.2 Where fixtures have been delamped, disconnect or remove the ballasts.	1053
9.2.3 Replace fluorescent lamps with high-efficiency or reduced-wattage types.	1054
9.2.4 Replace ballasts with high-efficiency or reduced-wattage types, or upgrade ballasts and lamps together.	1057
9.2.5 Install current limiters.	1064
9.2.6 Install fluorescent dimming equipment.	1066
9.2.7 Consider retrofit "reflectors" for fluorescent fixtures.	1069

Subsection 9.3: LAMPS AND FIXTURES, H.I.D. AND L.P.S.

9.3.1 Install the most efficient HID lamps, ballasts, and fixtures.	1073
9.3.1.1 For lowest retrofit cost, replace mercury vapor lamps with metal halide or high-pressure sodium lamps that do not require ballast replacement.	1078
9.3.2 Install HID dimming equipment.	1079
9.3.3 In appropriate applications, substitute fluorescent lighting for HID lighting.	1081

Subsection 9.4: LIGHTING CONTROLS, MANUAL

9.4.1	Install effective placards at lighting controls.	1086
9.4.2	Use security forces, watch engineers, or other regularly assigned personnel to keep unnecessary lights turned off.	1090
9.4.3	Install all single-pole toggle switches so that the toggle is down when the switch is off.	1091
9.4.4	Replace rheostat dimmers with efficient electronic dimmers.	1091
9.4.5	Where fixtures are not easily visible from the switch locations, install telltale lights.	1093
9.4.6	Draw attention to switches that should be used in preference to others.	1094
9.4.7	In applications where fixtures may be operated improperly by unauthorized personnel, use key switches.	1095

Subsection 9.5: LIGHTING CONTROLS, AUTOMATIC

9.5.1	Where lighting is needed on a repetitive schedule, use timeclock control.	1098
9.5.1.1	To combine time switching with daylighting, use astronomical timeclocks.	1100
9.5.2	Control exterior lighting with photocontrols.	1101
9.5.3	Install interior photocontrols to exploit daylighting.	1104
9.5.4	Where the need for lighting is determined by the presence of people, use personnel sensor switching.	1109
9.5.5	Where lighting can be turned off after a fixed interval, install timed-turnoff switches.	1111
9.5.6	If a door remains open when lighting is needed, use door switches.	1113

Subsection 9.6: LIGHTING LAYOUT

9.6.1	Make the surfaces of spaces highly reflective.	1116
9.6.2	Lay out lighting using the task lighting principle.	1119
9.6.2.1	Disconnect or remove fixtures where they are not needed.	1130
9.6.2.2	Relocate and reorient fixtures to improve energy efficiency and visual quality.	1133
9.6.2.3	Replace fixtures and improve fixture installations that waste light.	1135
9.6.3	Install fixtures or combinations of fixtures that provide efficient lighting for all modes of space usage.	1139
9.6.4	Install a separate control circuit for each lighting element that operates on a distinct schedule.	1141
9.6.4.1	Where light fixtures are needed in a predictable variety of patterns, install programmable switches.	1144
9.6.5	Install lighting controls at visible, accessible locations.	1145
9.6.5.1	Provide localized control of ceiling fixtures by installing pullcord switches.	1147

Subsection 9.7: FIXTURE MAINTENANCE AND MARKING

9.7.1 Clean fixtures and lamps at appropriate intervals.	1152
9.7.2 Replace darkened diffusers.	1153
9.7.3 In fixtures where the type or number of lamps may vary, mark the fixtures to indicate the proper type of lamp.	1155

Section 10: INDEPENDENT ENERGY-USING COMPONENTS**Subsection 10.1: A.C. INDUCTION MOTORS**

10.1.1 Install motors having the highest economical efficiency.	1162
--	------

Subsection 10.2: CENTRIFUGAL PUMPS

10.2.1 Trim pump impellers to match pump output to system pressure and/or flow requirements.	1178
10.2.2 Throttle the discharge of pumps to match system pressure and/or flow requirements.	1183

Subsection 10.3: FANS

10.3.1 Adjust the output of constant-flow fans to the minimum needed.	1188
--	------

Subsection 10.4: STANDBY EQUIPMENT

10.4.1 Install power switching that prevents unnecessary operation of standby equipment.	1194
---	------

Section 11. REFERENCE NOTES**Group 1. ENERGY MANAGEMENT TOOLS**

10. Clock Controls and Programmable Thermostats	1199
11. Personnel Sensors	1205
12. Placards	1213
13. Energy Management Control Systems	1219
14. Control Signal Polling	1227
15. Infrared Thermal Scanning	1229
16. Measurement of Liquid, Gas, and Heat Flow	1233
17. Energy Analysis Computer Programs	1239

Group 2. ENERGY SOURCES

20. Fossil Fuels	1247
21. Electricity Pricing	1251
22. Low-Temperature Heat Sources & Sinks	1259
23. Non-Fossil Energy Sources	1267
24. Characteristics of Sunlight	1283

Group 3. MECHANICAL COMPONENTS

30. Boiler Types and Ratings	1289
31. How Chiller Efficiency is Expressed	1297
32. Compression Cooling	1299
33. Absorption Cooling	1323
34. Refrigerants	1331
35. Centrifugal Pumps	1339
36. Variable-Speed Motors and Drives	1347
37. Control Characteristics	1379

Group 4. BUILDING ENVELOPE

40. Building Air Leakage	1385
41. How Insulation Works	1389
42. Vapor Barriers	1393
43. Insulation Selection	1397
44. Insulation Integrity	1404
45. Insulation Economics	1405
46. Daylighting Design	1407
47. Passive Solar Heating Design	1417

Group 5. LIGHTING

50. Measuring Light Intensity	1425
51. Factors in Lighting Quality	1427
52. Comparative Light Source Characteristics	1439
53. Lighting Efficiency Standards	1447
54. Incandescent Lighting	1449
55. Fluorescent Lighting	1461
56. HID and LPS Lighting	1473
57. Light Distribution Patterns of Fixtures	1483